

What makes the Sonic-Pro ultrasonic flowmeter stand out from the competition?

Everything...

Configuration -

Displays current configuration settings

Example:

1 = 1 inch nominal pipe size

D = doppler mode

0.00 = transducer separation distance

Goodness of measurement -

Measurement reliability metrics

Display -

320 x 240 Pixel QVGA Backlit LCD
UV resistant

LED status indicators -

Aids in installation and troubleshooting errors

Hybrid -

User selectable doppler or transit time operating mode

Power -

AC or DC power input

Outputs -

Isolated 4-20 mA output
0-1000 Hz pulse output
fully configurable, invertible

Data logging -

Over 500,000 log events possible with included 32 MB SD card (flash memory)

Process control -

Three independently configurable 10 amp form C, no/nc relays

Communications

Computer connection via RS-232, RS-485, USB, Ethernet
Includes user PC software

ProSeries™
by Blue-White Ind.

visit our website at www.blue-white.com
5300 Business Drive, Huntington Beach CA 92649